

Home Diffuser

OPERATION MANUAL



Languages

English	2	Français	34
Español	10	繁體中文	42
Svensk	18	简体中文	49
Deutsch	26		


Overview

Young Living's newly designed Home Diffuser combines the multifunctional benefits of a humidifier, air purifier, atomizer, and aromatherapy diffuser into one easy-to-use product. Its ultrasonic technology breaks the mixture of essential oils and water into millions of micro-particles and disperses it into the air, activating the powerful plant constituents found in Young Living essential oils. Its light-weight design allows you to enjoy these benefits in any room of your home and comes with a convenient, automatic shut-off feature (see Operating Instructions).

The Home Diffuser can be used to:

- **Transform your surroundings:** The ultrasonic frequency generates waves at 2.5 million times per second, releasing essential oil molecules into the air to help create a relaxing, spa-like atmosphere in your home or office.
- **Eliminate odors:** The ultrasonic technology gently disperses essential oils throughout a space, removing lingering smells without resorting to synthetic air fresheners.
- **Protect your family's health:** The Home Diffuser safeguards your family's health by replacing harmful household chemicals with effective, all-natural essential oils.
- **Humidity:** The Home Diffuser's constant, humidified air helps keep your skin moisturized and feeling fresh.

Contents



Operating Instructions

1. Open the water reservoir by lifting the clear lid. Add room-temperature water (purified or distilled water is recommended) into the reservoir up to the fill line. Do not exceed the fill line.
2. Add 8–12 drops of your favorite Young Living essential oil into the water.
3. Replace the clear lid to cover the water reservoir.
4. Plug in the Home Diffuser and push on/off button to start and stop diffusing.
5. When water runs out, the diffuser will automatically shut off.

Notice: Use caution on surfaces that are sensitive to water due to the mist output of the Home Diffuser.

Cleaning

If essential oil begins to build up on the ultrasonic plate of the Home Diffuser, gently wipe it off using the included cleaning sponge or a cotton swab dipped in rubbing alcohol. If essential oil begins to build up on the clear lid of the Home Diffuser, gently wipe it off using mild soap and water only. (Do not use aerosol sprays, solvents, or abrasives to clean the plastic housing.) Clean the ultrasonic plate regularly for best performance.

Notice: When removing excess water from the reservoir, pour from the rear of the diffuser to avoid spilling on the operating buttons or getting water in the internal air inlets. If water leaks into the air inlets, it will spill out through the bottom of the diffuser.

Specifications

Product Name	Home Diffuser
Operating Frequency	2.5±0.07 MHz
Atomized Molecule Diameter	3 micrometers
Mist Volume	75 ml/hr
Water Tank Capacity	130 ml
Coverage	10 sq. meters
Rated Power	18W (max)
Dimension	135mm×169mm
Weight	0.87 kg
Rated Voltage	AC100V-AC240V 50/60HZ/24V 750mA
Noise Level	<70 dB (at 10 cm)

Safety and Care Instructions

Please read and follow these safety guidelines closely to ensure safe operation of the Home Diffuser.

- Unplug the Home Diffuser immediately and discontinue use in the event of smoke or a burning smell.
- Never wrap the adaptor with cloth, paper, etc. Such actions may result in damage to the diffuser or fire.
- Never touch the adaptor with wet hands; electric shock or injury may occur.
- Do not disassemble or attempt to repair the Home Diffuser; this may void the warranty.
- Never immerse the diffuser in water.
- Unplug the adaptor when refilling, cleaning, or moving the diffuser.
- Keep the diffuser out of reach of children.
- Do not remove or place objects in the water reservoir during operation.
- Do not place your fingers in the water during operation; this may result in injury.
- Do not place acidic or alkaline chemicals in the reservoir.
- Use only included power adapter provided in the packaging or by YL.
- Do not shake diffuser.
- Any damage caused by the user does not qualify for replacement by YL.

Troubleshooting

When switched on, the diffuser does not operate.

Check that the adapter is securely plugged into the wall socket and the rear of the diffuser. Check that the water level is not past the fill line. If there is too much water adjust the water to the fill line and restart.

There is no mist or a lower amount of mist than usual.

Check the water level. If the water is above the fill line, carefully pour the excess through the rear of the diffuser well, avoiding internal air inlets. Refill the diffuser to the fill line and restart. Check for essential oil buildup on the ultrasonic plate. If oil buildup is present, read cleaning instructions. **The ultrasonic plate must be free of residual oil buildup for the Home Diffuser to operate properly.**

Lights do not work.

Press the "On" button to verify that the lights are not functioning. If the lights do not work, call Customer Care for further instructions.

Water is leaking from the top of the diffuser.

Make sure that the lid is properly covering the top opening of the diffuser. If it is not, adjust the lid properly to ensure a secure fit to prevent the diffuser from leaking.

Water is leaking from the bottom of the diffuser.

Water may have entered into the air inlets causing the water to exit through the drain holes at the bottom of the diffuser. Water will not damage the diffuser. Wipe off the diffuser and follow the pouring notice found under the cleaning instructions.

Young Living Home Diffuser Product Warranty

Young Living Essential Oils (YLEO), Thanksgiving Point Business Park, 3125 Executive Parkway, Lehi, Utah 84043, subject to the exclusions contained below, warrants its Home Diffuser product to be free from defects in materials and workmanship under normal consumer usage for a period of 12 calendar months from the date of original purchase.

This Warranty Does Not Cover:

1. Defects or damage resulting from use of the product in other than its normal and customary manner;
2. Defects or damage from misuse, accident, or neglect;
3. Defects or damage from use of other than distilled, demineralized, deionized, or purified bottled water;
4. Defects or damage from use of natural oils other than those supplied or sold by Young Living Essential Oils or an authorized distributor;
5. Defects or damage from use of materials other than those specified in 3.) and 4.) above;
6. Defects or damage from improper testing, operation, maintenance, installation, adjustment, or any alteration or modification of any kind;
7. Products disassembled or repaired by anyone other than Young Living Essential Oils' authorized agent so as to adversely affect performance or prevent adequate inspection, verification, and testing to verify any warranty claim. If there are any signs the diffuser had been opened, the warranty will be void;
8. Products with labels removed or illegible serial numbers;
9. Defects or damage due to overfilling;
10. Marring such as scratches on any plastic surfaces and externally exposed parts resulting from normal use; and/or
11. Damage resulting from normal wear and tear.
12. Do not use metal tools to clean the ultrasonic plate, this may damage the diffuser and will void the warranty.

This limited warranty is the buyer's exclusive remedy, applies to new diffusers purchased from Young Living Essential Oils, and is non-transferable.

Please retain your original purchase receipt. In the event of a warranty claim or return for repair, a copy of the purchase receipt should accompany the diffuser when shipped to YLEO.

In the event of a warranty claim or to purchase spare parts, please contact the Young Living Customer Care Department (CCD) at 1-800-371-3515 (6 a.m.–8 p.m. M–F and 7 a.m.–5 p.m. Saturday MT).

If it is determined by CCD that the diffuser is to be shipped back to YLEO, the buyer will need to send the product back in its original box (if available) with the power adapter, a copy of the original purchase receipt, and the YLEO Return Merchandise Authorization (RMA)# (displayed clearly on the receipt), which will be provided by CCD.

U.S. Shipping: Young Living Essential Oils Returns/ RMA# _____
142 East 3450 North
Spanish Fork, UT 84660

For all other market address and contact information, visit www.youngliving.com.

Please be sure to complete the YLEO return form and send back all the items listed for timely processing of your return.

NOTICE:

If YLEO has determined, based on an evaluation and inspection of the diffuser, that the defect or malfunction is covered under warranty, YLEO will send a replacement Home Diffuser at no additional charge.



3125 Executive Parkway
Lehi, UT 84043
www.youngliving.com